

9 CH / 11 CH:

CHANNEL		VALUE	FUNCTION
9ch	11ch		
1	1	000-255	<b>RED</b> 0%→100%
2	2	000-255	<b>GREEN</b> 0%→100%
3	3	000-255	<b>BLUE</b> 0%→100%
4	4	000-255	<b>AMBER</b> 0%→100%
5	5	000-255	<b>WARM WHITE</b> 0%→100%
	6	000-009	<b>COLOR MACRO</b> Null
		010-016	Color 1
		017-023	Color 2
		024-030	Color 3
		031-037	Color 4
		038-044	Color 5
		045-051	Color 6
		052-058	Color 7
		059-065	Color 8
		066-072	Color 9
		073-079	Color 10
		080-086	Color 11
		087-093	Color 12
		094-100	Color 13
		101-107	Color 14
		108-114	Color 15
		115-121	Color 16
		122-128	Color 17
		129-135	Color 18
		136-142	Color 19
		143-149	Color 20
		150-156	Color 21
		157-163	Color 22
		164-170	Color 23
		171-177	Color 24
		178-184	Color 25
		185-191	Color 26
		192-198	Color 27

		199-205	Color 28
		206-212	Color 29
		213-219	Color 30
		220-226	Color 31
		227-233	Color 32
		234-255	Color 33
		<b>CTO</b>	
		000	Null
		001-004	8000K
		005-009	7900K
		010-013	7800K
		014-018	7700K
		019-022	7600K
		023-027	7500K
		028-031	7400K
		032-036	7300K
		037-040	7200K
		041-045	7100K
		046-049	7000K
		050-054	6900K
		055-058	6800K
		059-063	6700K
		064-067	6600K
		068-072	6500K
		073-076	6400K
	7	077-081	6300K
		082-085	6200K
		086-090	6100K
		091-094	6000K
		095-099	5900K
		100-103	5800K
		104-108	5700K
		109-112	5600K
		113-117	5500K
		118-121	5400K
		122-126	5300K
		127-130	5200K
		131-135	5100K
		136-139	5000K
		140-144	4900K
		145-148	4800K
		149-153	4700K
		154-157	4600K
		158-162	4500K

		163-166 167-171 172-175 176-180 181-184 185-189 190-193 194-198 199-202 203-207 208-211 212-216 217-220 221-225 226-229 230-234 235-238 239-243 244-247 248-255	4400K 4300K 4200K 4100K 4000K 3900K 3800K 3700K 3600K 3500K 3400K 3300K 3200K 3100K 3000K 2900K 2800K 2700K 2600K 2500K
6	8	000-255	<b>DIMMER</b> 0%→100%
7	9	000-255	<b>DIMMER FINE</b>
8	10	000-005 006-123 124-127 128-168 169-208 209-249 250-255	<b>STROBE</b> Open Strobe from Slow to Fast Open Random Strobe (Speed 1) Random Strobe (Speed 2) Random Strobe (Speed 3) Open
9	11	000-029 030-039 040-049 050-059 060-069 070-099 100-109 110-119 120-122	<b>SPECIAL FUNCTION</b> (To activate following functions, stop in DMX value for at least 3 seconds.) Null Dimmer Curve: Linear Dimmer Curve: Square Law Dimmer Curve: Inv SQ Law Dimmer Curve: S Curve Null Led Frequency Setting Enable Led Frequency Setting Disable Null

	123	900Hz
	124	1000Hz
	125	1100Hz
	126	1200Hz
	127	1300Hz
	128	1400Hz
	129	1500Hz
	130	2500Hz
	131	4000Hz
	132	5000Hz
	133	6000Hz
	134	10KHz
	135	15KHz
	136	20KHz
	137	25KHz
	138-139	Null
	140-209	Null
	210-219	Dimmer Speed: Fast
	220-229	Dimmer Speed: Smooth
	230-239	Dimmer Speed: Tungsten
	240-249	Dimmer Speed: All Tungsten
	250-255	Null

(WW) 1 CH / 2 CH / 4 CH:

CHANNEL			VALUE	FUNCTION
1ch	2ch	4ch		
1	1	1	000-255	<b>DIMMER</b> 0%→100%
		2	000-255	<b>DIMMER FINE</b>
	2	3	000-005 006-123 124-127 128-168 169-208 209-249 250-255	<b>STROBE</b> Open Strobe from Slow to Fast Open Random Strobe (Speed 1) Random Strobe (Speed 2) Random Strobe (Speed 3) Open
		4	000-063 064-127 128-191 192-255	<b>DIMMER SPEED</b> Default to Unit Settings Fast Smooth Tungsten

(RGBW) 4 CH / 6 CH / 7 CH:

CHANNEL			VALUE	FUNCTION
4ch	6ch	7ch		
1	1	1	000-255	<b>RED</b> 0%→100%
2	2	2	000-255	<b>GREEN</b> 0%→100%
3	3	3	000-255	<b>BLUE</b> 0%→100%
4	4	4	000-255	<b>WHITE</b> 0%→100%
	5	6	000-255	<b>DIMMER</b> 0%→100%
	6	7	000-005 006-123 124-127 128-168 169-208 209-249 250-255	<b>STROBE</b> Open Strobe from Slow to Fast Open Random Strobe (Speed 1) Random Strobe (Speed 2) Random Strobe (Speed 3) Open
		5	000-007 008-015 016-023 024-031 032-039 040-047 048-055 056-063 064-071 072-079 080-087 088-095 096-103 104-111 112-119 120-127 128-135 136-143 144-151 152-159	<b>COLOR MACRO</b> Null Color 1 Color 2 Color 3 Color 4 Color 5 Color 6 Color 7 Color 8 Color 9 Color 10 Color 11 Color 12 Color 13 Color 14 Color 15 Color 16 Color 17 Color 18 Color 19

			160-167		Color 20
			168-175		Color 21
			176-183		Color 22
			184-191		Color 23
			192-199		Color 24
			200-207		Color 25
			208-213		Color 26
			214-219		Color 27
			220-225		Color 28
			226-231		Color 29
			232-237		Color 30
			238-243		Color 31
			244-249		Color 32
			250-255		Color 33